

定期交換・主要緊急保守部品 一覧表

No.	部品名	数量	備考
1	FAN 115V 70CFM 941-0009-07	1	適時
2	BELT TMG 1/5 P 3/8W 25L IN. 924-0007-01	1	適時
3	THERMOMETER DIGITAL POCKET 6202941	1	適時
4	BMX CALIBRATOR STICKS BACT/ALERT 206543	1	適時
5	PKGD SHOE, ROCK GUIDE 423200-901	1	適時
6	FAN FILTER/GRILL ASSEMBLY 120125-1	1	適時
7	KIT,UPDATE,DRAWER/LATCH,BTA3D 440600-1	1	適時
8	ARM ASSY AGIT LINKAGE DR 47107-1	1	適時
9	PULLEY MOTOR 47427-1	1	適時
10	KIT,IDLER PULLEY COMBO 47428-9001	1	適時
11	BMX COMBO MODULE KIT 6200943	1	適時
12	BMX LINKAGE MNT W/PULLEY COMBO 3D 6202515	1	適時
13	BMX COMBINATION MODULE USB UPGRADE KIT 410917	1	適時
14	BMX SMART-UPS SMT1500J LCD 100V JP 417270	1	適時
15	ARROW - SAMSUNG PRINTER ML3750ND 120V 418887	1	適時
16	ARROW - SAMSUNG PRINTER LPT CABLE 418901	1	適時
17	CALIBRATOR STICKS BACT ALERT 421931	1	適時
18	BATTERY 12V (APC-SU1400J) JP011	1	適時